


BEFORE USE:

Please read the instructions carefully. You must inspect the appliance including its cable and plug for any signs of damage. If the product is damaged, **DO NOT USE** and contact your supplier immediately for refund or replacement.

This product is only suitable for well insulated spaces or occasional use.

MYZEK®



V 2024-08

**INSTRUCTION
MANUAL FOR MODELS**

MICA HEATER

MY284861

| GENERAL INFORMATION

Thank you for choosing the Mylek mica heater. Please take time to carefully read and understand the entire instruction manual before using the product and then save it for future reference. We reserve the right for any errors in text or images and any necessary changes made to technical data. If you have any questions concerning operational or technical problems please contact our Customer Services on **0800 091 3171**.

| BEFORE USING THIS HEATER

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. This includes but is not limited to the following.

CAUTION

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge of the product. The appliance is to be operated by responsible adults only after reading and understanding these instructions. Children should be supervised at all times to ensure that they do not play with the appliance. Children under 16 years should not operate the unit or carry out maintenance and/or clean the unit. Any infirmed persons in the vicinity of the unit should be accompanied by a responsible and competent

able bodied adult. Remove the packing and make sure that the appliance is intact. If there is any doubt concerning the integrity of the unit do not use the appliance and contact our recommended after-sales service.

Do not leave any packaging materials within easy reach of children. Before switching on appliance check if the electrical voltage and frequency of the circuit correspond to those indicated on the appliance. Use the appliance only for the stated purpose, namely as a heater for domestic use. Do not use it for any other application as it could be dangerous.

| IMPORTANT SAFETY REQUIREMENTS

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate

- and clean the appliance or perform user maintenance.
- CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- The heater must not be located immediately below a socket-outlet.
- Means for disconnection having a contact separation in all poles must be incorporated in the fixed wiring in accordance with the wiring rules.
- For correct installation on the wall, thanks to refer to 'Installation on wall' part.



- **WARNING:** In order to avoid overheating, do not cover the heater.
- Do not use this heater if it has been dropped.
- Do not use if there are visible signs of damage to the heater.
- Use this heater on a horizontal and stable surface.
- Damage may occur if it is placed on a slope.
- Do not place the heater directly on a carpet as the heat generated may damage some carpets.

- Do not place the heater too close to a wall or any furniture.
- Do not place anything on top of the heater.
- Do not use the heater in wet or moist locations, for example, bathrooms and laundry areas, or in areas where paint or other flammable or volatile liquids are used or stored.
- **WARNING:** Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
- **WARNING:** To reduce the risk of fire, keep textiles, curtains, or any other flammable material a minimum distance of 1m from the air outlet.
- **PLEASE NOTE:** Household dust, lit cigarettes, candles and oil burners, combined with the convection effect of electric heaters can cause significant soot deposits to build up on the surface directly above and to the sides of the heater. This is not a fault of the heater. Extensive burning of candles or smoking in the operating environment of this product can produce heavy discolouration within a few months of use.

Notice to Landlords, Universities, Housing Associations, Charitable Associations Or Other Similar Associations:

It is your responsibility to your Tenants where these heaters are fitted to make sure Risk Assessments are carried out for these heaters and your Tenant's are fully trained on how to operate this heater correctly and safely. The Tenant's are also given a copy of these user instructions for guidance and understand the importance of reading them and keeping


them safe and at hand at all times. The Tenant's should also understand the safety importance of NEVER covering the heater or heater vents at any time for drying or warming garments, or any types of materials. The Tenant's should also be trained about the correct clearance around the heater at all times. Not following correct guidance and training could result in the unit overheating system activating, risk of fire, injury or even death.

THIS PRODUCT IS FOR ROOM HEATING
FOR HOUSEHOLD USE ONLY

| SPECIFICATIONS

Model No.	RATED VOLTAGE	RATED POWER
MY284861	AC230V, 50-60Hz	2000W

| STRUCTURE AND PARTS



| HOW TO USE

WARNING: The heater must only be operated in an upright position.

- To switch on the heater, turn the Power/Mode knob to the "I" or "II" position. After this, if the Power indicator is off, turn the Temperature knob clockwise until you hear a click.
- To switch off the heater, turn the Power/Mode knob back to the "0" (Off) position.
- To unplug the heater, switch it off and then pull its power plug out of the electrical outlet.

I: LOW HEATING MODE, 1000W

II: HIGH HEATING MODE, 2000W

| SETTING THE TEMPERATURE

- To increase the set temperature, turn the Temperature knob clockwise.
- To decrease the set temperature, turn the Temperature knob anticlockwise.
- The heater will turn its heating element on or off to maintain the set temperature. Note: After turning off its heating element, the heater will continue radiating heat for a while because of the unique properties of its heating element. To switch off the heater, turn the Power/Mode knob back to the "0" (Off) position. To unplug the heater, switch it off and then pull its power plug out of the electrical outlet.

| OVERHEAT PROTECTION

The heater is fitted with an overheat protection switch (thermal cutout) that will power off the heater automatically in case of overheating. If this occurs, follow the steps below to resolve the problem:

- Unplug the heater and allow it to cool fully.
- Check and remove the source of the overheating such as poor ventilation and item covering the heater.
- Follow the operation instructions to restart the heater.
- The heater should function normally again. If the problem persists, contact our Customer Service for advice.

| TIP-OVER PROTECTION

The heater is fitted with a tip-over switch that will cut off the power to the heater if it is tipped over. If this occurs, follow the steps below to resolve the problem:

- Unplug the heater and allow it to cool fully.
- Place the heater back on a flat, level and stable surface.
- Inspect the heater for damage.
- If and only if the heater is free from damage, follow the operation instructions to restart the heater.

- The heater should function normally again. If the problem persists, contact our Customer Service for advice.

| PAT TESTING

When used in a workplace, this product must be safety-tested yearly by a qualified electrician (PAT Tested) in order to comply with the Electricity at Work Regulations. We recommend that it is PAT tested regularly when used in a domestic environment.

| MAINTENANCE

1. Always disconnect the appliance and let it completely cool before any maintenance.
2. Use a vacuum cleaner to remove dust on grilles.
3. Clean the outside of the unit with a damp cloth and then dry it with a dry cloth. Never immerse the unit in water, nor let water drip into the unit.

| STORING

1. Always disconnect the appliance, let it completely cool and clean it before storing.
2. If you do not use the device for a long period, put back the unit and the instruction manual to the original carton and store in a dry and ventilated place
3. Do not place any heavy items on top of carton during storing as this may damage the appliance.

Information requirements for electric local space heaters

Model identifier(s): MY284861							
Item	Symbol	Value	Unit	Item	Unit		
Heat output				Type of heat input, for electric storage local space heaters only (select one)			
Nominal heat output	P _{nom}	2.0	kW	Manual heat charge control, with integrated thermostat	[no]		
Minimum heat output (indicative)	P _{min}	1.0	kW	Manual heat charge control with room and/or outdoor temperature feedback	[no]		
Maximum continuous heat output	P _{max,c}	2.0	kW	Electronic heat charge control with room and/or outdoor temperature feedback	[no]		
Auxiliary electricity consumption				Fan assisted heat output			
At nominal heat output	e _{lmax}	0.000	kW	Type of heat output/room temperature control (select one)			
At minimum heat output	e _{lmin}	0.000	kW	Single stage heat output and no room temperature control	[no]		
In standby mode	e _{lsb}	0.000	kW	Two or more manual stages, no room temperature control	[no]		
				With mechanic thermostat room temperature control	[yes]		
				With electronic room temperature control	[no]		
				Electronic room temperature control plus day timer	[no]		
				Electronic room temperature control plus week timer	[no]		
				Other control options (multiple selections possible)			
				Room temperature control, with presence detection	[no]		
				Room temperature control, with open window detection	[no]		
				With distance control option	[no]		
				With adaptive start control	[no]		
				With working time limitation	[no]		
				With black bulb sensor	[no]		
Contact details	Hygiene Supplies Direct Limited, Ground floor, Tayson House, Methley Road, Castleford WF10 1PA						



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

The importer retains his right to make changes in appearance and completeness of the item without preliminary notification to the customer.

The item is for indoor use only.

The manufacturer does not assume any liability for any damage caused directly or indirectly by not following this instruction manual, general safety rules, or interference in the construction of the product.

| SERVICE WARRANTY

Hygiene Supplies Direct guarantees the product free from defects in materials and workmanship for a period of 1 year from date of purchase. Should this unit be operated under conditions other than those recommended, at voltages other than the voltage indicated on the unit, or any attempts made to service or modify the unit, then the warranty will be rendered void. The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights. If you have any problems with this product, please call our Help Desk on **0800 091 3171** or email: **sales@hygienesuppliesdirect.com**

MYLEK[®]

Hygiene Supplies Direct Limited, Ground Floor, Tayson House,
Methley Road Castleford, West Yorkshire, WF10 1PA
declares that the Mylek Heaters are exclusively manufactured
and imported for Hygiene Supplies Direct Ltd.